



- 1 REMOVE SUPPLY DUCT TO APPROXIMATE LOCATION AND PREPARE DUCT FOR NEW. COORDINATE THE SCOPE OF REMOVAL OF DUCT FOR NEW LOCATION OF NEW PIPING.
- 2 TEMPORARY REMOVE 6" DUCT FOR NEW PIPING. SEE NEW WORK SHEETS.
- 3 RELOCATE EXISTING VARIABLE VOLUME BOXES AS NECESSARY TO ROUTE NEW PIPING. SEE NEW WORK SHEETS.
- 4 REMOVE SUPPLY DUCT BACK TO BRANCH FITTING. END CAP DUCT AND RE-INSULATE.
- 5 REMOVE SUPPLY DUCT AND DIFFUSERS TO APPROXIMATE LOCATION AND PREPARE DUCT FOR NEW. SEE NEW WORK SHEETS.